STERILL®§



USER MANUAL

Sterillo Ltd

Unit 9 • Stort Valley Ind Estate • Stansted Road Bishop's Stortford • Herts • CM23 2TU • UK

+44 1279 466500

info@sterillo.com

www.sterillo.com



WARNING: INJURY MAY OCCUR IF MISUSED



Prohibited

- Do not open the front panel electric shock risk.
- Never look directly at the UV bulb when in operation.
- Do not allow children or adults to pull or hang on the machine.



Do not allow unit to get excessively wet

- Place the unit away from direct water supplies.
- A suitably rated fused power supply is required.
- Ensure the correct power supply is used, if more than +/-10% the unit may malfunction.



Do not dismantle

- The power must be turned off during installation and maintenance.
- Ensure the unit has a reliable earth connection.



Follow instructions carefully


- This unit must be installed by a qualified electrician.
- If the power cord is damaged it must be replaced by the manufacturer, its service agent or a qualified person.
- A residual current device (RCD) with a rated residual operating current, not exceeding 30mA is recommended.
- Please use dedicated spur.
- In case of malfunction, switch off power immediately.



Environmental Protection

 Do not dispose of electrical waste with household waste, please recycle in appropriate facilities. Check with your Local Authority or retailer for recycling advice.

UV LAMP SPECIFICATION



Size	Lamp Total Length L1 (mm)	145±1.5
	Lamp Diameter D1 (mm)	12±0.2
	Lamp width	max 27
Component and materials	Quart 3 glass tube	
	Electrode	hot cathode
	Lead wire	molybdenum rod
	Lamp base	2G7
Performance	Power	9W
	Ultraviolet radiation intensity(µW/cm2)	>4500
	Stabilisation time	5 minutes
	Average life (h)	8000

PRE-INSTALLATION PRECAUTIONS

DO NOT install in the following places

- Where the temperature can be below -10°C or above 40°C.
- Where the unit may come into direct contact with excessive water.
- If the unit will be in direct or strong sunlight.
- If there is a lot of condensation in the environment.
- If there are corrosive, neutral or reductive gases present.
- 20m or more below, or 2000m or higher than, sea level.

LOCATION

- Ensure there is at least 500mm clear space above the machine.
- It is recommended that a minimum distance of 100mm should be left clear to either side of the unit.
- Avoid locations where people or doors might damage the unit.
- Choose a completely flat wall surface to mount the unit with the power cable above.

CLEANING & MAINTENANCE

External maintenance

Clean with a soft cloth. If the unit is very dirty use a soft, dampened cloth with a neutral cleaning agent, then polish with a soft, dry cloth.

- · Only use neutral cleaning agents.
- Do not use thinners, acidic or alkaline toilet cleaners or nylon brushes (they may damage the surface).
- · If using chemical cloths, read instructions first.
- Unplug the unit before maintenance.
 - Incorrect repair may result in danger for the user.
 - The guarantee does not cover damage which is caused by modifications, accident, misuse, abuse, neglect, commercial use or improper use.
 We reserve the right to change the product and the instructions without notice in accordance with the policy of continuous improvement.
- WARNING: This appliance contains a UV emitter.
 Do not stare at the light source.
 NEVER look directly at the bulbs when in operation.

 Ensure unit and power are switched off and remove the outer shell to access the lamp unit.

Remove lamp unit cover to reveal the dual bulb.
 Carefully clear the unit of any dust using a soft brush.

 Gently loosen the old lamp by holding the lamp holder in one hand and pulling the lamp upwards and away from the lamp holder.

 Replace the dual lamp with a new one by inserting it into the lamp holder and pushing it downwards until it clicks into position.
 Do not touch the new lamp with your bare hands.

Replace the cover.



PACKING LIST

A.	Rawplug	٤ 4
В.	30mm Wall Screws	٤ 4
C.	Instruction Manual	د 1
D.	Allen Key	د 1
F	Sterillo LINO Unit	, 1

STERILL® 8





Sterillo Ltd

Unit 9 • Stort Valley Ind Estate • Stansted Road Bishop's Stortford • Herts • CM23 2TU • UK

+44 1279 466500

info@sterillo.com

www.sterillo.com